


BIOMIMETIC Series:
BIOMIMETIC TOUR-CX (773052)




String Pattern

14 Mains

18 Cross

When you want use a new string.
 Please follow the direction of Picture.
 Start mains at 1. Tie off mains at 2.
 Start cross at 3. Tie off cross at 4.

BIOMIMETIC MAX HL (773053)




String Pattern

14 Mains

18 Cross

When you want use a new string.
 Please follow the direction of Picture.
 Start mains at 1. Tie off mains at 2.
 Start cross at 3. Tie off cross at 4.

BIOMIMETIC PRO LITE (773054)




String Pattern

14 Mains

19 Cross

When you want use a new string.
Please follow the direction of Picture.
Start mains at 1. Tie off mains at 2.
Start cross at 3. Tie off cross at 4.

AEROGEL Series: AEROGEL 130 (773055)




String Pattern

14 Mains

18 Cross

When you want use a new string.
Please follow the direction of Picture.
Start mains at 1. Tie off mains at 2.
Start cross at 3. Tie off cross at 4.

AEROGEL135 / AEROGEL PRO (773056-57)



String Pattern

16 Mains

19 Cross


When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.

BLACKSTORM FORCE (773058)



String Pattern

16 Mains

19 Cross

When you want use a new string.


Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4

FLUX Series:

FLUX 50 (773059)



String Pattern

16 Mains

19 Cross


When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.

FLUX 45 /FLUX 40 (773060-61)



String Pattern

16 Mains

19 Cross


When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4

FLUX 30 (773062)



String Pattern

16 Mains

18 Cross

When you want use a new string.


Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.

RAGE Series:

RAGE 35 /RAGE 30 (773063-64)



String Pattern

16 Mains

18 Cross


When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.

RAGE 25 / RAGE 20 (773065-66)



String Pattern

14 Mains

19 Cross


When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.

RAGE 15 / RAGE 10 (773067-68)



String Pattern

14 Mains

20 Cross

When you want use a new string.

Please follow the direction of Picture.

Start mains at 1. Tie off mains at 2.

Start cross at 3. Tie off cross at 4.